



MOTOFIZZ CAMPING SEAT BAG


OWNER'S GUIDE

Thank you for choosing a MotoFizz Camping Seat Bag from Aerostich/RiderWearHouse. This guide will provide tips on how to set-up, use and get the most from your new bag for many years and thousands of miles. Questions? Call 800 222 1994 or Email <products@aerostich.com>. Thanks again and good riding!

Attaching the bag to your motorcycle:

- 1) Set the bag on the rear seat/back rack
- 2) Securely attach loop side of the 4 included Seat Attachment Straps to your motorcycle.

Strap attachment examples:




- 3) Adjust strap lengths and firmly attach the strap buckles and bag buckles together.
- 4) Tighten straps to secure the bag to your motorcycle.



- 5) Use 'D' rings and additional straps to prevent excess shifting of the bag. (see below)
- 6) When bag is removed from the seat, use the Connecting Buckle to attach the Seat Attachment Straps together and tighten to secure to seat top.
- 7) Do not allow any part of the bag to have direct contact with any superheated areas, such as muffler or engine.

How to prevent the bag from shifting:

- 1) Use the shoulder strap by wrapping it to the rear fender or license plate, securing to bag 'D' rings.
- 2) Attach additional straps as needed to ensure a tight, secure fit to bike.
- 3) Do not allow any straps or buckles to hang down by the tires. This can cause an accident.
- 4) Uneven weight distribution of packed gear, as well as items attached with straps or bungees to the outer surface of the bag will also effect bag positioning. Check bag at regular intervals and tighten any loose straps.



Useful features:

* noted features available on Mid and Lg Bags only



Removable zippered belt pack*



Ends open for easy loading and access*



Beverage holster



Includes rain cover



Outer strap system to secure gear like foam pads, tents, etc.



Built-in bungee's and 'D' rings stow items you want to keep in reach



Easy access storage pouch under main flap - great for lunch or quick access items

How to care for the bag:

- 1) Clean with a damp towel and air dry away from direct sun.
- 2) Use mild soap to remove any dirt.
- 3) Do not use a detergent or washing machine. This will harm the fabric.

Use and safety warnings:

- 1) Do not use this bag at high speeds or sharp cornering, as shifting can occur.
- 2) For your safety, it is important to pack your items evenly.
- 3) Rain cover is not 100% waterproof, so protect items by wrapping in plastic bags. It is also a good idea to spray the cover with a water repellent. Secure cover to prevent flapping by tying with a strap, bungee cord or cargo net.
- 4) Check bag at regular intervals and tighten any loose straps.
- 5) For heavy loads and off road use, use extra straps.
- 6) Maximum weight is 22lbs. (30 for Large). Do not exceed these maximum weights.
- 7) Paint protector sheet will protect your bikes paint finish from buckles and straps.
- 8) Side pocket bag can be removed for easy carrying.
- 9) Replace any damaged straps to eliminate further damage or accidents.

Camping Seat Bag includes:

- | | |
|----------------------------------|--------------------|
| 1 – Cross Strap Connector | 1 - Rain Cover |
| 1 – Removable Pouch | 1 - Shoulder Strap |
| 4 – Seat Attachment Straps | 2 - Holder Straps |
| 1 – Accessory Strap (Large only) | |

