

StonGard Headlight Shield #3569, #4910, #4912 Owners Guide

Thank you for purchasing your StonGard Headlight Shield.
Please read the following recommendations before use:

Installation and Removal

1. You may want to first make a cutting template from paper or manila file folder material. This can help adjust for any curves in your headlight lens before cutting the Headlight Shield material.
2. The StonGard Shield adhesive is designed to be applied at room temperature. Do not pre-heat the adhesive.
3. The StonGard Shield material may be cut with a scissors, utility knife or Xacto knife.
4. The StonGard Shield adhesive may be most easily removed with 3M adhesive cleaner.

Cleaning

1. Use normal headlamp cleaning procedures using soapy water, Windex™, etc. Avoid harsh abrasives as these may scratch the Headlight Shield's surface.

WARNING

Do not use the StonGard Headlamp shield on small headlamps with oversize bulbs. The StonGard Headlamp Shield is a thermal insulator. Smaller (5" or less) headlamps having over-wattage accessory bulbs (80-100w, etc.) may produce enough additional heat to cause a thermal crack to occur in the headlamp glass that is directly beneath the StonGard Shield. This is not a warrantable defect in either the headlamp glass or the StonGard Headlamp Shield.

*If you have questions or comments, contact us at 218-722-1927
or email: products@aerostich.com*